



CTS Turbo B-Cool Oil Filter housing (Gen3 TSI) – 2017 Audi A4 shown

NOTE: These steps are similar on many different models with Gen3 TSI 1.8T or 2.0T engines. We do not accept any liability for incorrect installation or damage during the install.

Have the following tools at hand:

- 32mm socket
- Torque wrench
- O-ring pick or small screwdriver

Make sure the car is cooled off before starting the install. Never work on a hot motor. Step 1: Remove engine cover and locate the oil filter housing.



Step 2:

- Remove factory oil filter housing using 32mm socket.
- Remove oil filter.
- Carefully remove the filter cage by pushing it to the side of housing.



Carefully remove the filter cage by pushing it to the side of housing.

Step 3:

- Transfer oil filter cage to CTS housing. (It is difficult to press in)
- Install the oil filter and apply some pressure still you hear/ feel the oil filter cage clip into place.
- Transfer o-ring. Reinstall on vehicle, tighten to 25NM.





You are done!