



INSTALLATION GUIDE

CTS Turbo Audi 8V RS3 2.5T
INTAKE PIPE
CTS-IT-257



**20630 Mufford Crescent, Unit #309
Langley, British Columbia V2Y 2V9**

www.CTSTURBO.com

WHAT IS INCLUDED

1. CTS Turbo Throttle Pipe
2. Hose Clamps x4
3. Straight Silicone Coupler
4. Stepped Silicone Coupler



TOOLS REQUIRED

1. Pliers
2. Flathead Screwdriver or 10mm Socket
3. T30 Torx

NOTES

Vehicle used in this guide is a 2017 Audi RS3. Always make sure the car is safe to work on. Do not work on a hot motor. We do not accept any liability for incorrect installation or damage during the install.

STEP 1

Remove Engine Cover



STEP 3

Loosen the two hose clamps on the rubber boot section of the throttle pipe and remove.

**STEP 4**

Lift clip and
Disconnect Vacuum
Line



STEP 5

Remove T30 torx
from lower brace

**STEP 6**

Use Pliers to
remove the
constant tension
clamp on the
passenger side of
the throttle pipe.



STEP 7

Remove Throttle Pipe

**STEP 8**

Install the straight silicone coupler, do not tighten clamps.



STEP 9

Install Stepped silicone coupler to the airbox and insert the CTS Throttle Pipe into both couplers.

**STEP 10**

Tighten clamps and T30 Torx



STEP 11

Re-Install Engine
Cover

You're Done!

