

Fitting Instructions #TRC5000IS

Volkswagen MKVII Golf

Front Strut Relocation Mount

Note: The following installation must only be preformed by qualified persons using suitable equipment.

- Jack vehicle up and put on stands/hoist, remove the front strut.
- Remove OE rubber isolator.
- Align notch on TRC5000 top mount to the coil over thrust bearing.



- Insert shock stud through the washer in the centre of TRC5000. Using the original fastener, tighten top mount down onto strut. Ensure notches are aligned.



- Install Strut into front of vehicle and use supplied fasteners to secure top of strut to the body. When both sides are installed, carry out a wheel alignment.

