



INSTALLATION GUIDE

CTS TURBO B8/B8.5 AUDI A4/A5/ALLROAD/Q5 2.0T
CHARGE PIPE
CTS-IT-267



WHAT IS INCLUDED

1. CTS Charge Pipe
2. Hardware

NOTES

STEP 1

Disconnect the silicone from the OEM charge pipe.

**STEP 2**

Remove electrical connector.



STEP 3

Remove driver side wheel and wheel liner.



STEP 4

Remove the nuts securing the OEM charge pipe to the body.



STEP 5

Disconnect the lower silicone.

**STEP 6**

Remove the OEM charge pipe



STEP 7

Transfer sensor to the CTS charge pipe



STEP 8

Route the CTS charge pipe from underneath.



STEP 9

Connect lower silicone and charge pipe.

**STEP 10**

Secure charge pipe with OEM nut.



STEP 11

Connect upper silicone and CTS charge pipe.



STEP 12

Connect the electrical connector.

Reinstall wheel liner and wheel and you are done!

