

P-FLO KIT FOR AUDI TT(8N) 180HP / VW BEETLE 1.8T GOLF IV & JETTA IV 1.8T / 2.0L

PART # 65.10.72B & 65.10.87B INSTALLATION INSTRUCTIONS



PARTS LIST: 1 - P-FLO AIR BOX $2 - \frac{1}{4}$ " $x20x^{5}/_{8}$ " HEX BOLTS

1-NEUSPEED AIR FILTER $2-\frac{1}{4}$ "x20 NYLOC NUTS 2-M6 ACORN NUTS 2-RUBBER MOUNTS

TOOLS REQUIRED: 1 - SCREW DRIVER $1 - \frac{7}{16}$ SOCKET

1-10mm SOCKET $1-\frac{7}{16}$ "WRENCH

1 – PLIERS 1 – 6" OR LONGER SOCKET EXTENSION

- 1. Unplug Mass Air Flow (MAF) sensor wire. Squeeze spring clamp or loosen hose clamp that holds the air intake hose to the MAF sensor, and pull hose off MAF.
- 2. Remove the two screws on back side of air filter housing and lift off top cover. Then remove the two bolts (10mm) located at front and back of lower portion of air filter housing and remove.
- 3. Remove MAF (two screws) from top cover. Using supplied bolts and nyloc nuts ($\frac{7}{16}$ "), attach the MAF to the engine side of P-Flo air box with the electrical connector facing toward the rear.
- 4. Hand-tighten supplied rubber mounts into original air box mounting holes on vehicle.
- 5. Install completed assembly onto study on rubber mounts using the acorn nuts supplied. NOTE: Use tape in socket to hold acorn nut when installing. Re-clamp the air intake hose to the MAF sensor; connect MAF sensor wire into harness.
- 6. Install NEUSPEED air filter. Be sure to recheck filter clamp for tightness a week later.
- 7. Carefully double-check complete installation. TEST DRIVE CAREFULLY!

©Copyright 2005, NEUSPEED®. All rights reserved. Reproduction in whole or in part prohibited. DOC.65.10.72&87 Rev. 04.15.05